

RUTGERSON

Rutgerson - Changing the lid of the Classic Hatch manual - English

This manual describes the process of removing the lid of a Classic hatch installed on deck, and then attaching a new lid.

1. Loosen the bolt on the side of the hinge, using an Allen key. (Round hatch has one hinge and the other shapes have two hinges each)

2. Once the bolts are removed, open the lid and try to wiggle it until it comes off.

3. If the bolts cannot be removed and the lid does not come off, carefully push the bolts out of the hinge using a chisel or a screwdriver. Make sure not to damage the composite frame that is installed on the deck.

The reason why this step might be necessary is that the 500x500 square, round and half-round hatches have conical instances inside the hinge.

4. When the bolts are taken out, remove the lid from the hatch.

5. Attach the new lid to the inner frame in the deck by tightening the bolts on the side of the hinge(s).

